


BPW AIR SUSPENSION - O, OM, OT SERIES



O-SERIES

1. Leaf Spring
2. Bush
3. Bolt
4. Washers
5. Lock Nut
6. Spring Plate
7. Segment
8. Lock Nut
9. "U" Bolt
10. Shock Absorber
11. Mounting Bolt
12. Washer
13. Lock Nut
14. Air Spring